


## DESCRIPTION

- 1 Delivery casing
  - 2 Screw
  - 3 External jacket
  - 4 O-Ring
  - 5 Screw
  - 6 Washer
  - 7 Wear ring (1)
  - 8 Suction washer
  - 9 First stage casing
  - 10 Stage casing
  - 11 Last stage casing
  - 12 Impeller
  - 13 Impeller nut
  - 14 Washer
  - 15 Oil chamber cover
  - 16 Mechanical seal
  - 17 Retaining ring, split
  - 18 Shoulder ring
  - 19 Spacer
  - 20 Spacer sleeve
  - 21 Motor cover, pump side
  - 22 O-ring
  - 23 O-ring
  - 24 Cable gland
  - 25 Upper mechanical seal
  - 26 Circlip
  - 27 Pump side bearing
  - 28 Motor jacket with winding
  - 29 Float switch
  - 30 Jacket cover
  - 31 Shaft with rotor packet
  - 32 O-ring
  - 33 Bearing
  - 34 Motor end-shield, non-drive end
  - 35 Screw
  - 36 O-ring
  - 37 Compensating spring
  - 38 Cable.
- Inserted in stage casing,  
cannot be supplied separately



Supplied by: